

Gigaware™

## Start Here

16-952

Quick Start

### 7" Digital Photo Frame


#### Package contents




Photo Frame




AC Adapter



#### ② Insert your Memory Card



#### ① Connect to AC Outlet



#### ③ Use the Photo Frame

